









Control lines shall consist of ropes, wires, tapes or equivalent materials, and supporting stanchions, and each must be:

- Flagged or otherwise clearly marked at not more than 6-foot intervals with a high-visibility material
- Rigged and supported in such a way that the lowest point (including sag) is not less than 39 inches from the walking/working surface and the highest point is not more than 45 inches --nor more than 50 inches when overhand bricklaying operations are being performed—from the walking/working surface
- Strong enough to sustain stress of not less than 200. Control lines shall extend along the entire length of the unprotected or leading edge and shall be approximately parallel to the unprotected or leading edge.
- Control lines will be connected on each side to a guardrail system or wall.

When control lines are used, they shall be erected not less than 6 feet nor more than 25 feet from the unprotected or leading edge, except when precast concrete members are being erected. In the latter case, the control line is to be erected not less than 6 feet nor more than 60 feet or half the length of the member being erected, whichever is less, from the leading edge.

Controlled access zones when used to determine access to areas where overhand bricklaying and related work are taking place are to be defined by a control line erected not less than 10 feet nor more than 15 feet from the working edge. Additional control lines must be erected at each end to enclose the controlled access zone. Only employees engaged in overhand bricklaying or related work are permitted in the controlled access zones.

Notes













