

OMNIKEY®

Smart Card Reader

Base Models: 3121, 5127 CK, 3111, 5121, 5125

Weight Information:

Standard Standing Base: 1.09 oz (31 g) Heavy Standing Base with Middle Piece: 3.52 oz (100 g) Jumbo Standing Base with Middle Piece: 15.2 oz (431 g)

ASSEMBLY PROCEDURE

3121-914, Rev A.0 April 2012

© 2012 HID Global Corporation. All rights reserved.

Standard Vertical Mounting



Pull the cable through the cut-out found in the reader back.

Place the cable in the base cut-out. Tuck the reader using the guide bars into the round opening and press until it snaps.

Standard Adhesion to a PC Monitor or Usage without Base

OR



Lift off the pad (reader back) for use without the base.



After removing the blue foil, attach the reader to a monitor, etc.

Horizontal Mounting



Place the middle piece on the base. The upper and base parts fit together when matching both cut-outs.

After removing the adhesion pad, the round opening has a counterpart on the base assembly. A small guidance bar at the back ensures stable assembly.

HID GLOBAL, HID, the HID logo, and OMNIKEY are the trademarks or registered trademarks of HID Global Corporation, or its licensors, in the U.S. and other countries.